



Magnetic Air Vent Mount Instructions - Ver 1.0

Call 888-722-5240 with any question about installation during the hours of 8am to 5pm Monday - Friday, Pacific Time



Step 1: Determine if you will adhere the 3M adhesive to the back of your phone or back of your phone case.

Step 2: Remove the protective layer from the adhesive and adhere to the case or device.

Step 3: On the back of the magnetic mount, loosen the round knob. Insert the ball end of the clip into the opening of the round knob until it snaps into place. Tighten the round knob.

Step 4: To install the Air Vent Clip, select which air vent you wish to use. The clip can be installed vertically or horizontally on any air vent.

Step 5: Once you have selected the air vent of your choosing, insert the clip onto one of the vents and then tighten the wing nut adjusters clockwise until tight.

Step 6: Use the round knob adjuster to select the preferred angle. At this point, you may want to place the phone on the mount to find the desired angle. Be sure to tighten this knob counter clockwise when finished.

<http://www.heininger.biz>

Bellingham, Washington 98229 USA

Limited Liability, 90 Day Warranty Policy

Heininger Holdings, LLC, warrants the original owner of each new CommuteMate product against defects in workmanship and materials for 90 Day from the date of purchase (at retail) of the product, provided it is purchased from an authorized CommuteMate product dealer. This Limited 90 Day Warranty is not transferable and shall only apply to normal and ordinary use, for which the product was intended, as described in the Instructions provided.

Warranty claims are to be made directly to Heininger Holdings and must be accompanied by a sales receipt or other appropriate proof-of-purchase document. Should this product or any part or accessory be determined by Heininger Holdings, to be defective and covered by this Limited 90 Day Warranty, it will be repaired or replaced at the option of Heininger Holdings, without further charge. The cost of transportation to and from the referred warranty inspection facility for repair or replacement of any defective part and/or accessory and any related charges is not covered by this warranty, and is to be paid by the owner.

The warranty does not cover normal wear and tear, worn and normal use cosmetic blemishes, improper assembly, lack of maintenance, or custom alteration/installation of any parts or accessories not originally intended or compatible with the product as sold. The warranty does not apply to damage or failure resulting from an accident, abuse or neglect.

This warranty is given in lieu of all other expressed warranties, implied warranties, including without limitation implied warranties of merchandising ability and fitness for a particular purpose, and are limited to the duration and specification of this warranty. In no event shall Heininger Holdings, be liable for damages in excess of the purchase price of the CommuteMate product, for any loss of use, loss of time, inconvenience, commercial loss, lost profits or savings or any incidental, special, consequential, direct or indirect damages arising out of the use or inability to use such product, to the full extent as such may be disclaimed by the law. Labor charges for part changeover are not covered by this warranty.